



Exterior Deep Cleaner
Removes dirt, stains and rejuvenates

Technical_Data_Sheet_Label

01.03.2021 - p. 1/2

Exterior Deep Cleaner is an intensive cleaning product, which rejuvenates patinated outdoor wood. It is a ready-mixed, thick-flowing product, which is easy to apply, even to vertical surfaces. Exterior Deep Cleaner penetrates deep into the wood and removes dirt, coatings and grey patina. For optimum protection, the wood should be treated with WOCA Exterior Wood Oil after cleaning.

- **Thick viscosity**
- **Easy to apply**
- **Deep cleaning**
- **Non drip**
- **Removal of dirt, coatings and grey patina**



AppArea

Suitable for outdoor wooden decks, wall coverings, fences, garden furniture etc. Ideal for all types of wood.

Work_Descrip_Label

Preparation_Label Cleaning should be done in dry (ideally overcast) weather, as the cleaner must not be allowed to dry out. Avoid direct sunlight and excessive heat. Soak the wood, using plenty of water. Use a garden hose if possible.
Exterior Deep Cleaner is ready-mixed and should not be diluted.

Always remember to test on a less visible spot to check the compatibility of the surface with the product.

Treatment The wood must be soaking wet before application of Exterior Deep Cleaner. Using a brush or spray gun, apply Exterior Deep Cleaner as a smooth, uniform layer and allow the cleaner to work. After approximately 15-20 minutes, scrub the wood using a stiff-bristled brush. We recommend that you use WOCA silicon brush for the best results. Rinse off the Exterior Deep Cleaner, using plenty of water and a stiff-bristled brush. The wood must be left to dry for at least 48 hours, before application of WOCA Exterior Wood Oil.

NoteTxt If a completely smooth surface is desired, de-nip the wood with a grain 180-240 sanding pad before oiling.

DryingTime

DryingTime 48 hours at 59-68° F



Techdata_label

Declaration	Less than 5%: cationic surfactants.
Density	1.02 kg/L
PHVvalue	<1
ShelfLife	24M
AppTemp	+ 50-77° F, ideally cloudy weather.
Consumption	Approx. 86-108 ft ² /L
Colours	Transparent
CleaningTools	Use water
Storage	+10-25°C. Keep out of reach of children. Do not expose to heat (e.g. sunlight). Store frost-free during winter and cool during summer.
AvailPotSizes	2.5 L - 5 L

MaintenanceProd

ApplicationTool	Spray gun
	Outdoor Scrubbing Brush, #599601
	Silicium Brush, #88055
	Hand Scrubber Flex Kit, Red, #599750
	Hand Scrubber Flex Kit, White, #599752

Contact_Label

WOCA Denmark A/S
Tværevej 6
DK - 6640 Lunderskov
T +45 9958 5600
info@wocadenmark.com
wocadenmark.com

Disclaimer_Long